

Flushing Instructions

The office of the Water Resources Commissioner (WRC) would like to inform you that work was recently performed in your area and your water service line may need flushing.

Please follow the instructions below to remove any particles that may have broken loose inside your pipes and to maintain the quality of the water in your home:

- 1.** Open the outdoor water faucet closest to your water meter. Allow it to run for approximately 5 minutes.
 - a.** If there is no outside faucet, begin at the interior faucet closest to your water meter after removing the aerator (the little screen that is screwed onto the end of each faucet).
 - b.** If you cannot remove some faucet aerators, flush the faucets where you can first.
- 2.** Repeat this same process on all faucets inside your home using the cold tap only. Begin with the faucets at the lowest level of the home.
- 3.** Continue with the cold water faucets at the lowest level of your home and one-by-one, systematically fully open the faucets throughout your home.
- 4.** Allow the cold water to run for at least 5 minutes from each faucet. Don't forget to include your bathtubs and showers.
- 5.** Turn off each faucet beginning with those located at the highest level of your home.
- 6.** Clean and reinstall all faucet aerators.

During this process:

- Do not drink the water during this process. This flushing process is meant to stir up sediment in your pipes to rinse it out. After this process is completed, you may use your water as usual.
- Do not use hot water or open any hot water faucets.
- Do not use an ice maker or a filtered water dispenser until the flushing process is complete.

Instrucciones para descargar

La oficina del Comisionado de Recursos de Agua (WRC, por sus siglas en inglés) desea informarle que recientemente se han realizado trabajos en su zona y su línea de servicio de agua puede necesitar una descarga.

Siga las instrucciones a continuación para eliminar cualquier partícula que puede haberse desprendido dentro de sus cañerías para mantener la calidad del agua en su hogar:

- 1.** Abra el grifo de agua exterior más cercano a su medidor de agua. Déjelo correr durante aproximadamente 5 minutos.
 - a.** Si no hay un grifo exterior, comience con el grifo interior más cercano al medidor de agua, tras retirar el aireador (la pequeña pantalla atornillada al final de cada grifo).
 - b.** Si no puede retirar los aireadores del grifo, descargue primero los grifos que pueda.
- 2.** Repita este proceso en todos los grifos dentro de su hogar utilizando solo el agua fría.
- 3.** Continúe con los grifos de agua fría en el nivel más bajo de su hogar y abra por completo sistemáticamente y uno a uno los grifos en todo el hogar.
- 4.** Haga correr agua fría para durante al menos 5 minutos en cada grifo. No olvide incluir sus bañeras y duchas.
- 5.** Apague cada grifo comenzando por aquellos ubicados al nivel más alto de su hogar.
- 6.** Limpie y vuelva a instalar todos los aireadores de los grifos.

Durante este proceso:

- No beba el agua durante este proceso. Este proceso de descarga tiene como finalidad remover el sedimento en sus cañerías para retirarlo. Después de completar este proceso, puede utilizar su agua como de costumbre.
- No utilice agua caliente ni abra los grifos de agua caliente.
- No utilice una hielera ni un dispensador de agua filtrada hasta completar el proceso de descarga.